Product warranty card

product name	
product model	

Manufacturing day	
Purchase day	

ultimate user
name of organization: address: contacts: telephone:

distributor
contacts: Telephone Seal

Note: the blank parts above must be filled in truthfully by the end user and the sales store, otherwise there is no warranty.(see the back for warranty period and terms)

The LED imaging lamp is used

Production, protect, product, repair, say, card, Ming

Model：LCX200

（Please read this instruction in detail before using the lamp）

First of all, thank you for purchasing LED series lamps. Please read this manual carefully before use and operate according to the regulations to avoid personal safety and damage by misuse.

Box list: one set of lamps, one manual, one warranty card.

direction for use:

After unpacking, carefully check whether the lamps are damaged due to transportation. Before power supply, please check whether the lamp position is correct and whether the power supply voltage matches, otherwise the damaged lamp is not within the scope of warranty and can be used normally.

The product belongs to class I protection equipment. The bottom line of the power supply must be grounded and needs to be operated by professionals. Check the power supply voltage. If the power supply voltage fluctuates greatly, it is recommended to use 110v-230v voltage regulator or voltage regulator

technical parameter

Rated voltage: AC110 / 230V + 10% rated frequency: 50Hz~60Hz

Rated power: 200W light source: 150 / 200 / 250 / 300W

Number of lamp beads: 1 color: positive white, warm white, double color

Channel number: 6 / 2 DMX512 channel working environment: indoor, outdoor

Control mode: self-go, DMX512, main-slave synchronization

1、图解部分：



Ⓐ MENU
Ⓑ UP
Ⓒ DOWN
Ⓓ ENTER

2．Operation instructions：

When power on, the display of the last operation is displayed. Press B / C to select different function effects (refer to the menu). The last two digits represent the position of this function Address code Or parameters of speed and. Press B or C to modify the parameter value.

3．数码显示窗功能对照表

1	A001	A001Select the address code, press the up or down key to select the address code, and press the OK key to save the address code
2	R255	Manual color adjustment: when there is no console, use the up or down key to adjust the brightness between r000-r255, and press the OK key to save
3	G25	Manual green adjustment. When there is no console, use the up or down key to adjust the brightness between g000-g255, and press the OK key to save
4	T000	
5	S-32	For the number of wireless remote control machines, press the up / down key to select the number of remote control lamps (s-01-s-99), and press the OK key to save. Up to 90 units,
6	Id01	Wireless remote control ID address, press the up / down key to select the ID address between (id01-id99), and press the OK key to save

4、Dual color dmx6 channel function introduction：

A channel	D channel	Channel function
channel 1	channel 1	Total dimming W, WW total dimming, linear dimming, from dark to bright
channel 5	channel 2	W dimming, W from dark to bright
channel 6	channel 3	WW dimming, WW from dark to
channel 2	channel 4	Strobe, from slow to fast
channel 3	channel 5	Built-in mode
channel 4	channel 6	Built-in mode speed

5、 Introduction of monochrome channel function:：

Achannel	Channel function
channel 1	W dimming, W from dark to bright
channel 2	Strobe, from slow to fast
D channel	Channel function
channel 1	W dimming W from dark to bright

6、DMX-512 address code setting method:

cresset	start address
1	001
2	017
5	065

- **Primary and slave synchronization function considerations:**

1. When the host and lamps will send DMX-512 signals, it is forbidden to connect DMX-512 console at this time, which will interfere with each other and cannot operate.